

BlickM overview

each column shows one parameter: pan idlocationstatuslive statusissuescalibrations

sort for parameter

for details and editing, select parameters in instrument's row

click parameter to view details and edit

search for Pandora ID or location

search...

Pan ID	Location	Status	Live Status	Issues	Calibrations	Operator
2	GreenbeltMD		L0	hw.sp.uv.cm hw.pc.bo hw.sh.f2.se		LShalaby
16	GreenbeltMD					LShalaby
17	Busan		L0	hw.sh unknown		LShalaby
18	Beltsville			cn.it hw.tr.zm.se		LShalaby
19	LabGSFC					LShalaby
20	NewHavenCT			hw.tr.de		LShalaby
21	GreenbeltMD		L0	hw.tr.zm		LShalaby
23	FourCornersNM			cn.it		LShalaby

status

operational

operational with issues

intensive care

testing

laboratory

hold due to issue

out of operation

live status

<30min

>=30min & <24h

>=1d

time since last L0 file transmission

issues

critical

minor

connection

no category

calibrations

calibrations performed and varified

calibrations performed but not varified

no calibration

Instrument overview: timelines of status, issues and location
-log of all actions and comments

PanID

scroll to zoom, click/drag to pan

filter list below to time range above and reset filter

create comment on instrument operation or any relevant condition affecting operation

status lines show sun search parameters and spectrometer temperature for last 24h, click back/forward to change the day. Full status line as list on mouse over.

azimuth

zenith

rms

not successful

direction of correction

color: type of search

icons

issue opened / closed

comment

status changed

location changed

location

relocate instrument

new location

or edit old

select new location from dropdown menu if location not in list, click location and login (admin. only)

enter time and optional description

save or cancel

status

change status

new status

or edit old

select new status

enter time and reason

save or cancel

issues

open or close issue

new issue

or close / edit old

select issue category and description (or search) if category or description not in list, click category or description and login (admin. only)

enter time (open or close)

save or cancel

calibrations

enter calibration

new calibration

or edit old

select lab routine (L0 to LT) that has been performed

select which routine has been verified

enter comment

enter time (opened or closed)

save or cancel